

PATENT APPLICATION  
IN THE UNITED STATES PATENT AND TRADEMARK OFFICE

In re the application of: Attorney Docket No.: 2950.20US01  
Chaloner-Gill et al. Confirmation No.: 2942  
Application No.: 09/845,985 Examiner: Mark Ruthkosky  
Filed: April 30, 2001 Group Art Unit: 1745  
For: PHOSPHATE POWDER COMPOSITIONS AND METHODS FOR FORMING PARTICLES  
WITH COMPLEX ANIONS

---

DECLARATION UNDER 37 C.F.R. § 1.132

Mail Stop Amendments  
Commissioner for Patents  
P.O. Box 1450  
Alexandria, VA 22313-1450

Sir:

I, Craig R. Horne, Ph.D., hereby declare as follows:

1. I am presently CEO of EnerVault Inc., an early stage energy storage company. I was awarded my Ph.D. in Materials Science & Mineral Engineering from the University of California, Berkeley in 2000. I have nine published technical papers, have been active in the Electrochemical Society and have refereed papers for the Journal of the Electrochemical Society. I am presently an occasional consultant to the assignee, NanoGram Corp., on matters relating to battery technology. I have been an employee or consultant to NanoGram, its parent company NeoPhotonics or its majority owned subsidiary Kainos Energy Corporation since I departed school at UC Berkeley in 1998. I am an inventor on 15 issued U.S. Patents and numerous U.S. and foreign pending applications. More details on my qualifications are found on the attached resume. Dr. Horne has an equity interest in NanoGram Corp., but has no other specific pecuniary interest in the present application.

2. I am an inventor on the patent application noted above that is presently under examination. I am familiar with the pending claims.

3. I have carefully read U.S. patent 5,538,814 to Kamauchi et al. (Kamauchi), U.S. patent 5,789,115 to Manev et al. (Manev), and U.S. patent 5,910,382 to Goodenough et al. (Goodenough).

4. I worked with Dr. On Chang to reproduce the formation of lithium cobalt phosphate and lithium iron phosphate based on the teachings of the Kamauchi patent. Specifically, we followed a procedure similar to the procedure of Example 1 of the Kamauchi patent. The details of this procedure are summarized in detail in my Declaration with Dr. Chang filed on April 6, 2006, which had an attached report.

5. The as synthesized phosphate powders were processed using ball milling. The Kamauchi patent does not describe their milling techniques in detail. However, Example 7 at column 18 describes ball milling as a suitable milling approach. Similarly, Example 10 describes milling in a ball mill for 24 hours. This is the approach that we adopted for processing of the phosphate powders. A commercial ball mill was used, and the powders were milled for 24 hours. During the course of our work, we consulted with commercial milling companies and mill product suppliers. It was our belief that our milling approach was state of the art milling as of the filing date of the present application, April 30, 2001. The results of our phosphate particle processing were described in detail in the attached report entitled "Grinding of Lithium Cobalt Phosphate Mixed Phase Material (Li-Co-PO<sub>4</sub>) and Lithium Iron Phosphate (LiFePO<sub>4</sub>)," which was attached to the Horne-Chang Declaration of April 6, 2006, and a copy of which is also attached to this Declaration.

6. I have read the relevant parts of the Board of Appeal Decision of December 19, 2008 and the Decision on Request for Rehearing of July 14, 2009.

7. To summarize the results of the grinding experiment, the ground phosphate powders were evaluated using both visual evaluation of scanning electron micrographs (SEM) and light

scattering of powders dispersed in a liquid. Transmission electron micrographs were not obtained since these would not have been meaningful beyond the SEM photos due to the large particles in the samples and the large range of particle sizes. The non-uniformity of the powders is readily observable in the SEM photographs, which clearly show tiny particles as well as relatively large chunks. These results are consistent with the light scattering results, which clearly show a very broad distribution of particle sizes.

Plots in the attached report show the particle size distribution by volume as well as by particle number for the two phosphate samples. The light scattering results were performed with an ultrasonic probe to break agglomerates. This state of the art dispersion approach should be very effective at separating particles within agglomerates. The light scattering measurements were performed by an independent contractor proficient in the measurement technique based on samples that we provided. In my experience, light scattering will result in a narrower distribution than a TEM analysis for at least two reasons. First, there is small particle drop out in the light scattering measurements, so the small diameter part of the distribution is under represented or absent. Also, agglomeration tends to involve more smaller particles so that you bias the distribution toward the middle.


8. To facilitate the understanding of the results by the Patent Office, I am providing additional comments and interpretations of the results.

9. The functional property most valuable to an active electrode material in a lithium battery is the specific energy. A material's specific energy is defined as the product of its insertion potential, measured in Volts, and its specific capacity, measured in mAh per unit weight of material (most commonly as mAh/g). The insertion potential is a property that is intrinsic to a given material composition as it relates to its underlying electronic structure. However, the specific capacity will depend markedly on the quality of the material. Therefore, for a given composition of active insertion electrode material (e.g.  $\text{LiFePO}_4$ ), the specific capacity of a sample fabricated by a given process provides the most useful comparative value to assess its quality to the quality of a sample fabricated by a different process.

The specific capacity is a gravimetric function as it is normalized to unit mass. Therefore, as is the case with mass, the capacity of a particle relates to its volume and therefore,

the cube of its diameter. This means that if Particle 2 is twice the size of Particle 1, Particle 2 will have eight times the capacity of Particle 1. Accordingly, though a small number of large particles within a given collection does not significantly impact the size distribution, they will have a dramatic impact on the distribution as it relates to the material property of interest, capacity. Therefore, when evaluating the impact of a given fraction of particles outside a range of interest within a collection of active insertion electrode materials for lithium batteries, the percentage with respect to the mass (e.g. cube of the size or calculated volume) is the governing parameter to consider.

A comparison of the distributions calculated on a number % and mass % is presented below. Referring to Table A, the number % data are from Columns B1 and C1 for Li-Co-PO<sub>4</sub> and LiFePO<sub>4</sub>, respectively, while the mass% data are from Columns E3 and F3 for Li-Co-PO<sub>4</sub> and LiFePO<sub>4</sub>, respectively.



10. To obtain the average particle size, conventional analysis is used. An average is defined as the sum of the values divided by the number of values. When using a normalized distribution, the equivalent of the number of values is equal to 1. The numerator becomes the sum of the product of the probability times the diameter value. In other words, the average diameter  $d_{ave}$  is calculated as follows:  $d_{ave} = \sum d \cdot p_d$ , where  $d$  is the diameter and  $p_d$  is the weighted probability.

Referring then to Tables 5 and 6 in the Report, the diameter is given in one column and the probability is the difference in a percentage value in the second column minus the previous percentage value in the table divided by 100 to remove the percentage value. Table A, presented at the end of this Declaration, shows the average diameter calculated in this manner for Li-Co-PO<sub>4</sub> (cols. B1 to B3\_ and LiFePO<sub>4</sub> (cols. C1 to C3). Columns A and B1 comprise of the data of Table 5 in the Report while Columns A and C1 are of Table 6. The probability of each diameter being present in a sample is calculated in Columns B2 and C2 while Columns B3 and C3 give the product of the diameter and probability. Therefore, the sum of Columns B3 and C3, given at the bottom, provide the average particle size of each sample based on the data provided in the Report.

As mentioned above, the cumulative mass fraction distribution is the governing parameter to consider when determining the impact of particle size on the functional properties of active insertion electrode materials for lithium batteries. Column D in Table A is the cube of the size given in column A and therefore represents the volume of a specific measurement channel. Columns E1 and F1 use the observation probability data of Columns B2 and C2 along with the densities for Li-Co-PO<sub>4</sub> and LiFePO<sub>4</sub>, respectively<sup>1</sup>, to calculate the mass of particles associated with each measurement interval (Columns A and D). The total sum of Columns E1 and F1 are used to calculate the mass % probability shown in Columns E2 and F2. Finally, the data in Columns E2 and F2 are used to calculate the cumulative mass % distributions given in Columns E3 and F3 for Li-Co-PO<sub>4</sub> and LiFePO<sub>4</sub>, respectively.

Based on this analysis, the average diameter for Li-Co-PO<sub>4</sub> is 0.225 microns, and the average diameter for LiFePO<sub>4</sub> is 0.200 microns (data shown in Table A).

<sup>1</sup>. Densities of Li-Co-PO<sub>4</sub> is taken as that of LiCoPO<sub>4</sub>. Densities of both LiCoPO<sub>4</sub> and LiFePO<sub>4</sub> found in Table A were taken from J. Chen et al., Solid State Ionics **178**(2006)1676-1693.

Table B. Calculated arithmetic mean size, 5x mean size, and % greater than 5x mean size (from data in Tables 5 and 6 of Report for Li-Co-PO <sub>4</sub> and LiFePO <sub>4</sub> , respectively).						
sample	mean size, $\mu\text{m}$	5x mean size, $\mu\text{m}$	number % greater than 5x mean size	number % less than 0.40x and greater than 1.6x mean size	mass % greater than 5x mean size	mass % less than 0.40x and greater than 1.6x mean size
Li-Co-PO <sub>4</sub>	0.225	1.125	0.73	22.33	59.7	91.4
LiFePO <sub>4</sub>	0.200	1.000	0.50	16.39	45.6	87.0

11. Table B above shows that for Li-Co-PO<sub>4</sub>, 5 times the average diameter is 1.125 microns. Referring to Table A, col. B1 (also given in Table 5 of the Report), about 0.73 percent of the particles have a size greater than 5 times the average particle size, as denoted by the bold red type. As specified in claim 1, essentially no particles have a size greater than 5 times the average size. Therefore, the ground materials fail to come close to this claimed feature. The impact of this failure is illuminated by Table A, col. E3. Since the material capacity is a gravimetric function (mAh/g), more than 59% of the total mass in given sample of particles is comprised of particles whose mass is 5x the mean.

12. Table B above shows that for LiFePO<sub>4</sub>, 5 times the average diameter is 1.000 microns. Referring to Table A, col. C1 (also given in Table 6 of the Report), about 0.50 percent of the particles have a size greater than 5 times the average particle size, as denoted by the bold red type. As specified in claim 1, essentially no particles have a size greater than 5 times the average size. Therefore, the ground materials fail to come close to this claimed feature. The impact of this failure is illuminated by Table A, col. F3. Since the material capacity is a gravimetric function (mAh/g), more than 45% of the total mass in given sample of particles is comprised of particles whose mass is 5x the mean.

13. Referring to Table A, column B1 (also Table 5 in the Report), our claim 55 specifies that no more than 5% of the particles have a size less than 40 percent of the average particle size and greater than 160 percent of the average particle size. From the distribution in Table A, column B1 (also Table 5 in the Report), about 10% of the particles have a diameter less than 40% of the average (0.090 microns), as denoted by bold magenta type, and about 12.5% of the particles have

a particle size greater than 160% of the average particle size (0.360 microns), as denoted by bold orange type. Therefore, more than 22% of the particles falling outside this size range. Therefore, the uniformity obtained by milling also fell very short of the uniformity claimed in claim 55 of our application. The impact of this failure is illuminated by Table A, col. E3. Since the material capacity is a gravimetric function (mAh/g), more than 93% of the total mass in given sample of particles fall outside the specified range.

14. Referring to Table A, column C1 (also Table 6 in the Report), our claim 55 specifies that no more than 5% of the particles have a size less than 40 percent of the average particle size and greater than 160 percent of the average particle size. From the distribution in Table A, column C1 (also Table 6 in the Report), about 4% of the particles have a diameter less than 40% of the average (0.080 microns), as denoted by bold magenta type, and about 12% of the particles have a particle size greater than 160% of the average particle size (0.320 microns), as denoted by bold orange type. Therefore, more than 16% of the particles falling outside this size range. Therefore, the uniformity obtained by milling also fell very short of the uniformity claimed in claim 55 of our application. The impact of this failure is illuminated by Table A, col. F3. Since the material capacity is a gravimetric function (mAh/g), almost 92% of the total mass in given sample of particles fall outside the specified range.


15. Based on my extensive personal experience processing these types of materials and personal discussions with service providers, the milling of inorganic materials to produce specific results is relatively unpredictable. In general, milling for submicron materials is not expected to yield uniform materials, although new milling techniques under present development may improve on this circumstance when the technologies become more mature. Based on this generally known understanding, a person of ordinary skill in the art reading the Manev patent would have no expectation that milling of the Kamauchi materials would be successful to form the claimed highly uniform phosphate particles.

16. In summary, our experimental results confirm the expectations of a person of ordinary skill in the art that milling is simply incapable for producing uniform materials as disclosed and claimed in our patent application. Milling was not close to achieving the properties of the

claimed materials. These particle size measurements clearly demonstrate that conventional grinding approaches cannot produce phosphate powders with close to the uniformity of the phosphate powders claimed in the pending claims of the present application.

17. I declare that all statements made herein that are of my own knowledge are true and that all statements that are made on information and belief are believed to be true; and further that these statements were made with the knowledge that willful false statements and the like so made are punishable by fine or imprisonment, or both, under Section 1001 of Title 18 of the United States Code and that such willful false statements may jeopardize the validity of the application or any patent issued thereon.

9/22/2009  
Date

  
Craig R. Horne, Ph.D.

CERTIFICATE OF ELECTRONIC TRANSMISSION

I hereby certify that this paper is being transmitted electronically to the U.S. Patent and Trademark Office on the date shown below.

September 22, 2009  
Date

/Peter S. Dardi/  
Peter S. Dardi, Ph.D., Reg. #39,650



Table A. Particle size data reductions showing cumulative number % and number % and calculated arithmetic mean size (columns B and C) and corresponding mass %, and cumulative mass % (columns E and F) for Li-Co-PO<sub>4</sub> and LiFePO<sub>4</sub> from data in Report tables 5 and 6, respectively.

col. A	col. B <sub>1</sub>	col. B <sub>2</sub>	col. B <sub>3</sub>	col. C <sub>1</sub>	col. C <sub>2</sub>	col. C <sub>3</sub>	col. D	col. E <sub>1</sub>	col. E <sub>2</sub>	col. E <sub>3</sub>	col. F <sub>1</sub>	col. F <sub>2</sub>	col. F <sub>3</sub>
size channel, µm	Cumulative number % (from Table 5)	weighted number %	weighted size for mass %	Cumulative number % (from Table 6)	weighted number % %	weighted size for mass %	calculated volume channel, µm <sup>3</sup>	mass in range, µg	density #	3.322	mass in range, µg	density #	3.322
0.075	1.83	1.33	0.28E-04	1.57	1.18E-05	1.57	0.00022	1.14E-09	0.07097	0.00071	1.25E-09	0.01666	0.0267
0.090	3.60	2.27	6.35E-05	4.34	2.67	1.14E-05	0.00027	2.37E-09	0.02146	0.00217	2.59E-09	0.03414	0.0511
0.085	5.22	2.82	2.48E-05	7.65	3.81	5.33E-06	0.00032	3.69E-09	0.02226	0.00446	3.95E-09	0.0627	0.104
0.090	5.22	3.36	3.33E-05	11.57	5.35	3.33E-06	0.00035	4.99E-09	0.0508	0.0115	5.39E-09	0.07713	0.176
0.093	13.34	3.66	4.49E-05	15.79	4.23	4.01E-06	0.00043	7.89E-09	0.0395	0.0145	8.35E-09	0.0920	0.267
0.100	17.39	3.65	3.89E-05	20.20	4.41	4.44E-06	0.00052	9.85E-09	0.0512	0.015	8.35E-09	0.1109	0.378
0.106	11.36	3.97	4.21E-05	24.70	4.30	4.77E-06	0.00061	9.64E-09	0.0512	0.015	8.35E-09	0.1346	0.512
0.113	23.39	4.05	4.55E-05	39.22	4.52	5.11E-06	0.00078	1.19E-08	0.0772	0.026	1.25E-08	0.1622	0.676
0.119	29.44	4.05	4.82E-05	33.70	4.48	5.39E-06	0.00088	1.39E-08	0.0859	0.035	1.25E-08	0.1894	0.866
0.126	33.49	4.05	5.10E-05	38.12	4.42	5.71E-06	0.00105	1.65E-08	0.0305	0.044	1.67E-08	0.2214	1.05
0.134	37.34	4.02	5.39E-05	42.45	4.35	5.96E-06	0.00126	1.97E-08	0.0218	0.056	1.97E-08	0.2512	1.35
0.142	41.48	3.97	5.68E-05	46.66	4.23	5.96E-06	0.00150	2.33E-08	0.143	0.249	2.26E-08	0.303	1.65
0.150	45.37	3.89	5.84E-05	50.74	4.08	6.12E-06	0.00177	2.68E-08	0.165	0.314	2.56E-08	0.346	2.00
0.159	49.15	3.81	6.06E-05	54.67	3.93	6.25E-06	0.00210	3.13E-08	0.193	0.411	2.96E-08	0.397	2.40
0.169	52.89	3.71	6.27E-05	58.44	3.77	6.37E-06	0.00253	3.65E-08	0.226	0.511	3.43E-08	0.458	2.86
0.179	56.49	3.60	6.44E-05	62.05	3.61	6.46E-06	0.00300	4.21E-08	0.260	0.59	3.91E-08	0.521	3.38
0.188	59.94	3.47	6.59E-05	65.47	3.42	6.46E-06	0.00353	4.77E-08	0.295	0.69	4.36E-08	0.584	3.96
0.198	63.29	3.35	6.66E-05	68.72	3.25	6.50E-06	0.00419	5.43E-08	0.335	0.773	4.91E-08	0.654	4.61
0.200	63.29	3.35	6.66E-05	68.72	3.25	6.50E-06	0.00492	6.17E-08	0.362	0.860	5.50E-08	0.733	5.35
0.212	66.47	3.18	6.74E-05	71.65	3.06	6.49E-06	0.00566	7.03E-08	0.435	0.94	6.17E-08	0.822	6.17
0.215	69.50	3.05	6.82E-05	74.65	2.87	6.46E-06	0.00706	7.89E-08	0.486	1.03	6.79E-08	0.908	7.07
0.218	72.36	2.86	6.82E-05	77.32	2.67	6.35E-06	0.00818	8.77E-08	0.542	1.07	7.49E-08	0.993	8.07
0.232	75.05	2.69	6.78E-05	79.80	2.48	6.25E-06	0.0100	9.77E-08	0.604	1.11	8.26E-08	1.071	9.17
0.247	77.57	2.52	6.73E-05	82.10	2.30	6.14E-06	0.0119	1.08E-07	0.660	1.14	9.05E-08	1.157	10.4
0.263	79.91	2.34	6.63E-05	84.20	2.10	5.94E-06	0.0141	1.19E-07	0.713	1.17	9.79E-08	1.247	11.7
0.300	82.08	2.17	6.53E-05	86.11	1.81	5.73E-06	0.0165	1.30E-07	0.766	1.19	1.06E-07	1.337	13.0
0.318	84.07	1.99	6.33E-05	87.65	1.74	5.53E-06	0.0196	1.43E-07	0.869	1.21	1.13E-07	1.432	14.6
0.336	85.85	1.81	6.13E-05	89.42	1.57	5.28E-06	0.0236	1.55E-07	0.943	1.23	1.19E-07	1.528	16.2
0.348	87.45	1.66	5.91E-05	90.81	1.40	4.99E-06	0.0281	1.65E-07	1.000	1.24	1.26E-07	1.625	17.8
0.373	89.05	1.50	5.67E-05	92.06	1.24	4.69E-06	0.0335	1.75E-07	1.050	1.25	1.34E-07	1.727	19.6
0.400	90.28	1.34	5.36E-05	93.17	1.11	4.44E-06	0.0399	1.89E-07	1.080	1.26	1.42E-07	1.830	21.5
0.424	91.59	1.20	5.05E-05	94.14	0.97	4.17E-06	0.0471	1.97E-07	1.230	1.27	1.49E-07	1.940	23.4
0.449	92.86	1.07	4.80E-05	94.98	0.84	3.77E-06	0.0561	2.07E-07	1.28	1.28	1.56E-07	2.05	25.4
0.475	94.61	0.89	4.53E-05	95.72	0.74	3.53E-06	0.0661	2.16E-07	1.33	1.29	1.64E-07	2.16	27.5
0.503	96.44	0.69	4.17E-05	96.36	0.64	3.22E-06	0.0785	2.25E-07	1.39	1.30	1.73E-07	2.26	29.5
0.533	97.17	0.73	2.89E-05	96.90	0.54	2.28E-06	0.0795	2.25E-07	1.39	1.30	1.73E-07	2.26	29.5

col. 4	col. 5	col. 6	col. 7	col. 8	col. 9	col. 10	col. 11	col. 12	col. 13	col. 14	col. 15	col. 16	col. 17	col. 18	col. 19	col. 20
size channel, µm	Cumulative number % (from Table 5)	col. 8, µm	col. 9, µm	col. 10, µm	col. 11, µm	col. 12, µm	col. 13, µm	col. 14, µm	col. 15, µm	col. 16, µm	col. 17, µm	col. 18, µm	col. 19, µm	col. 20, µm	col. 21, µm	col. 22, µm
0.555	59.31	0.64	3.61E-05	97.37	0.47	2.46E-08	0.0054	calculated volume channel, µm <sup>3</sup>	col. 10 range, µg	col. 11 range, µg	col. 12 range, µg	col. 13 range, µg	col. 14 range, µg	col. 15 range, µg	col. 16 range, µg	col. 17 range, µg
0.590	64.36	0.35	3.12E-05	97.77	0.40	2.39E-08	0.112	2.40E-07	1.45	1.80E-07	1.45	1.80E-07	2.13	31.6		
0.625	68.55	0.49	3.11E-05	98.11	0.34	2.18E-08	0.133	1.54E-07	1.43	2.01	1.61E-07	2.13	33.2			
0.671	72.73	0.42	3.10E-05	98.40	0.29	1.95E-08	0.153	1.39E-07	1.37	2.17	1.84E-07	2.13	36.0			
0.711	77.63	0.31	2.78E-05	98.65	0.25	1.72E-08	0.153	1.24E-07	1.30	2.33	1.95E-07	2.20	38.2			
0.753	82.25	0.31	2.45E-05	98.83	0.21	1.38E-08	0.154	1.09E-07	1.63	24.9	1.70E-07	2.26	40.4			
0.798	86.23	0.27	2.15E-05	99.03	0.17	1.19E-08	0.168	9.68E-08	1.72	28.6	1.69E-07	2.26	42.7			
0.845	89.45	0.24	1.90E-05	99.13	0.14	1.06E-08	0.173	8.48E-08	1.73	28.4	1.65E-07	2.17	44.9			
0.893	92.87	0.21	1.68E-05	99.31	0.13	1.14E-08	0.173	7.07E-08	1.82	30.2	1.71E-07	2.23	47.1			
0.940	96.05	0.18	1.71E-05	99.42	0.11	1.04E-08	0.173	6.12E-08	1.90	34.0	1.77E-07	2.38	49.5			
1.005	99.01	0.16	1.61E-05	99.52	0.20	1.00E-08	0.173	5.21E-08	2.05	36.1	1.92E-07	2.35	51.4			
1.064	99.45	0.14	1.49E-05	99.59	0.070	7.45E-04	0.611	3.24E-07	2.10	36.1	1.92E-07	2.13	54.4			
1.117	99.27	0.12	1.39E-05	99.66	0.070	7.45E-04	0.611	3.24E-07	2.10	36.1	1.92E-07	2.13	54.4			
1.164	99.35	0.11	1.31E-05	99.72	0.060	7.16E-04	0.611	3.24E-07	2.10	36.1	1.92E-07	2.13	54.4			
1.205	99.47	0.090	1.14E-05	99.77	0.050	6.32E-04	0.611	3.24E-07	2.10	36.1	1.92E-07	2.13	54.4			
1.240	99.63	0.080	1.07E-05	99.81	0.040	5.56E-04	1.369	3.92E-07	2.12	47.1	1.92E-07	2.13	56.6			
1.319	99.63	0.070	9.95E-04	99.84	0.030	4.26E-04	1.496	4.09E-07	2.32	49.3	1.92E-07	2.16	58.2			
1.363	99.65	0.060	9.02E-04	99.87	0.030	4.31E-04	1.776	4.19E-07	2.37	52.5	1.92E-07	2.16	58.2			
1.392	99.73	0.050	7.96E-04	99.89	0.020	3.18E-04	2.113	4.11E-07	2.34	55.0	1.92E-07	2.03	75.3			
1.506	99.77	0.040	6.74E-04	99.91	0.020	3.37E-04	2.509	5.01E-07	2.41	57.5	1.92E-07	2.41	78.7			
1.706	99.81	0.040	7.14E-04	99.92	0.020	1.79E-04	2.865	4.54E-07	2.87	60.3	1.00E-07	1.43	77.3			
1.892	99.84	0.030	5.68E-04	99.94	0.020	3.78E-04	3.546	4.14E-07	2.56	62.9	2.56E-07	3.41	80.6			
2.004	99.87	0.030	6.01E-04	99.95	0.020	2.00E-04	4.314	4.92E-07	3.04	63.9	1.31E-07	2.02	82.6			
2.223	99.89	0.020	4.25E-04	99.96	0.020	2.12E-04	5.020	5.90E-07	2.41	62.3	1.81E-07	2.41	85.0			
2.249	99.91	0.020	4.50E-04	99.96	0.000	0.00E+00	5.956	4.64E-07	2.87	71.2	0.00E+00	0.00	85.0			
2.382	99.92	0.010	2.59E-04	99.97	0.010	2.31E-04	7.077	6.55E-07	1.70	72.3	1.95E-07	3.40	88.4			
2.523	99.94	0.020	5.05E-04	99.97	0.000	0.00E+00	8.409	7.92E-07	4.05	76.3	0.00E+00	0.00	88.4			
2.673	99.95	0.010	2.49E-04	99.98	0.010	2.67E-04	10.000	3.89E-07	2.41	79.3	5.90E-07	4.80	94.1			
2.891	99.96	0.000	0.00E+00	99.99	0.010	3.00E-04	11.850	4.81E-07	2.86	82.2	0.00E+00	0.00	94.1			
2.999	99.97	0.010	3.18E-04	99.99	0.000	0.00E+00	14.123	0.00E+00	0.00	82.2	5.09E-07	6.79	100.0			
3.177	99.97	0.000	0.00E+00	99.99	0.000	0.00E+00	25.393	0.00E+00	0.00	59.2	0.00E+00	0.00	100.0			
3.355	99.97	0.000	0.00E+00	99.99	0.000	0.00E+00	28.190	0.00E+00	0.00	59.2	0.00E+00	0.00	100.0			
3.541	99.98	0.010	5.96E-04	99.99	0.000	0.00E+00	33.453	1.90E-06	8.35	100.0	0.00E+00	0.00	100.0			
3.778	99.98	0.010	4.00E-04	99.99	0.000	0.00E+00	39.798	0.00E+00	0.00	100.0	0.00E+00	0.00	100.0			
4.225	99.99	0.000	0.00E+00	99.99	0.000	0.00E+00	47.351	0.00E+00	0.00	100.0	0.00E+00	0.00	100.0			
4.713	99.99	0.000	0.00E+00	99.99	0.000	0.00E+00	59.221	0.00E+00	0.00	100.0	0.00E+00	0.00	100.0			
5.203	99.99	0.000	0.00E+00	99.99	0.000	0.00E+00	68.234	0.00E+00	0.00	100.0	0.00E+00	0.00	100.0			
5.793	99.99	0.000	0.00E+00	99.99	0.000	0.00E+00	74.417	0.00E+00	0.00	100.0	0.00E+00	0.00	100.0			
5.949	99.99	0.000	0.00E+00	99.99	0.000	0.00E+00	81.935	0.00E+00	0.00	100.0	0.00E+00	0.00	100.0			
5.984	100.00	0.010	3.99E-04	100.00	0.010	5.98E-04	113.193	2.37E-06	19.5	100.0	2.37E-06	4.00	100.0			
total mass								1.67E-05 µg (per 10.000 µm <sup>2</sup> area)								1.67E-05 µg (per 10.000 µm <sup>2</sup> area)

# **Grinding of Lithium Cobalt Phosphate Mixed Phase Material (Li-Co-PO<sub>4</sub>) and Lithium Iron Phosphate (LiFePO<sub>4</sub>)**

On Chang and Craig Horne

NanoGram Corporation

## **BACKGROUND**

The purpose of this experiment is to evaluate the particle size distribution of metal phosphate nanoscale particles produced by following the teaching of U.S. Patent 5,538,814, the Kamauchi patent. For completeness, this demonstration was performed on two separate metal phosphate systems: (a) the Li-Co-PO<sub>4</sub> mixed-phase material that is the specific example in the Kamauchi patent, and (b) LiFePO<sub>4</sub>.

## **EXPERIMENTAL**

### **Chemicals**

Cobalt (II) carbonate hydrated: Sigma-Aldrich, Cat. No. 202193, Lot No. 05130JC  
Lithium carbonate: Sigma-Aldrich, Cat. No. 255823, 99% ACS grade, Lot No. 08004KC  
Phosphoric acid: Ashland chemical, 85%, semiconductor grade  
Iron (II) Oxide: Sigma-Aldrich, Cat. No. 400866, 99.9%, Lot No. 13722PC

### **Equipment**

Jar mill: One-tier jar high-capacity laboratory jar mill, 13" roller, Cole Parmer, Cat. No. EW-04149-00  
Milling jar: HDPE milling jar, 0.25 gal, with ridges on the interior to improve tumbling of the grinding media. Cole Parmer Cat. No. EW-04172-02  
Milling jar sleeve: Milling jar sleeve, Cole Parmer Cat. No. EW-04172-12  
Grinding media: Zirconia grinding media, 3/8" x 3/8. Cole Parmer Cat. No. EW-04158-10. About 2.37kg (750 pieces) of the grinding media were used per milling jar.  
Sieve: USA standard test sieve, No 10. (2mm). Stainless steel frame and wire, 8" diameter. Cole Parmer Cat. No. EW-59984-01.

### **Approach**

The chemical precursors were first evaluated to determine the molar amount of metal per unit weight of precursor. The established molar quantities were then used to determine the precursor quantities yielding the desired metal ratio. The respective precursors were weighed and mixed, calcined, and finally milled following the methods prescribed in the Kamauchi patent. The synthesized materials were analyzed for phase content by X-ray diffraction and particle size by several methods.


## **RESULTS AND DISCUSSION**

### **Precursor Analysis**

The cobalt (II) carbonate hydrated as purchased contains unknown amount of hydrated water. It is necessary to determine the water content in order to achieve an accurate stoichiometry.

Before the analysis, it is necessary to allow the cobalt (II) carbonate sample to reach equilibrium with normal lab atmosphere so that no water will be gained or lost during sample handling. To achieve this, about 20 g of cobalt (II) carbonate was placed on a dish and exposed to normal lab atmosphere for 14 hours. Then the exposed cobalt (II) carbonate was analyzed with TGA (thermogravimetric analyzer) to determine the water content from the weight loss. The TGA ramp rate was 10C/min. The atmosphere was 4% H<sub>2</sub> in N<sub>2</sub>. The result is shown in Figure 1.

Figure 1. TGA Curve of Cobalt (II) Carbonate Hydrated



The total wt loss from room temp to 500C was about 54.8%, corresponding to CoCO<sub>3</sub> 8.0 H<sub>2</sub>O (MW= 262.9). The amount of water in excess of the amount corresponding to the known hexa-hydrated form (see, for example "Merck Index") is probably due to absorbed water. Since water of hydration does not form with Li<sub>2</sub>CO<sub>3</sub> or FeO, and the P precursor was in liquid form, this analysis was not required to generate the necessary molar quantities of lithium, iron, or phosphorous per gram of their respective precursors.

#### Synthesis of materials

The respective precursor chemicals were used for the synthesis of Li-Co-PO<sub>4</sub> and LiFePO<sub>4</sub> according to the teachings of the Kamauchi patent. Note that the precursor mixing method used in this experiment, grinding in a mortar and pestle, is more detailed and thorough than that described in the Kamauchi patent (see Appendix A). The mortar and pestle mixing employed in this experiment tends to reduce precursor particle size. Therefore, this approach will help minimize product particle size thus making the experiment more favorable towards achieving the results asserted in the Kamauchi patent.

#### Synthesis of Li-Co-PO<sub>4</sub> mixed-phase material

According to the Kamauchi patent, it is understood that the product, hereafter referred to as Li-Co-PO<sub>4</sub> positive electrode material mix, is not a pure phase, but is a mixture of lithium phosphate, lithium cobalt phosphate, and lithium cobalt oxide. The amounts of

starting materials actually used in this experiment are shown in Table 1 and yielded a Li:Co:P atomic (mole) ratio of 2:1:1. The atomic ratio used matches that used in Example 1 of the Kamauchi patent (Appendix A).

Table 1. Amounts of Starting Materials for the Synthesis of Li-Co-PO<sub>4</sub> Material Mix

Materials	Molar mass	Wt (g) used	Moles	Atomic ratio
Li <sub>2</sub> CO <sub>3</sub>	73.88	4.984	0.06746	2.00
CoCO <sub>3</sub> 8.0 H <sub>2</sub> O	262.9	17.75	0.06752	1.00
H <sub>3</sub> PO <sub>4</sub> , 85% solution	98.00	7.785	0.06752	1.00

Li<sub>2</sub>CO<sub>3</sub> and CoCO<sub>3</sub> 8.0 H<sub>2</sub>O were weighed out and mixed with mortar and pestle for about 10 minutes. After grinding, the color was uniformly pink. Then phosphoric acid was added and mixing continued for another 20 minutes. Within a few minutes after adding phosphoric acid, foaming due to generation of CO<sub>2</sub> was observed. After the mixing, the power appeared dry. The color was pink.

The mix was then placed in a crucible and heated in the furnace. The temperature was ramped up at 10 C/min to 900 C, then held at 900 C for 24 hours. The weight of the reaction mix before heating was 29.535g. The weight of the product mix after heating was 17.382g. After heating, the product was in the form of a soft cake of powder. The color of the product was dark gray. The product was later ground and milled, as described below.

#### Synthesis of LiFePO<sub>4</sub> material

According to a journal article (Padhi, 1997, see Appendix B), the mole ratio of Li, Fe and P should be 1:1:1. The amounts of starting materials actually used in this experiment for the synthesis of LiFePO<sub>4</sub> are shown in Table 2.

Table 2. Amount of Starting Materials for the Synthesis of LiFePO<sub>4</sub>

Materials	Molar mass	Wt (g) used	Moles	Atomic ratio
Li <sub>2</sub> CO <sub>3</sub>	73.88	4.889	0.06617	1.00
FeO	71.85	9.511	0.13237	1.00
H <sub>3</sub> PO <sub>4</sub> , 85% solution	98	15.31	0.1328	1.00

Li<sub>2</sub>CO<sub>3</sub> and FeO were first weighed out and ground together with mortar and pestle for 20 minutes. After grinding, the color was uniformly gray. Then H<sub>3</sub>PO<sub>4</sub> was added. Gas (presumably CO<sub>2</sub>) was generated. After mixing of the above material, the material was dark gray and mud-like. The material was heated under nitrogen at 300°C for one hour. After heating, the material forms brittle lumps. The color was not uniform, from light gray to dark gray. The material was then ground with a mortar and pestle. Then the material was further heated under nitrogen at 800°C for 24 hours. After heating, the product was in the form of a sintered hard cake. The product color was not uniform,

from gray to beige. Some of the material adhered to the crucible tightly and could not be collected. The product was also later ground and milled, as described below.

#### **Grinding of materials**

The Li-Co-PO<sub>4</sub> positive electrode material mix and the LiFePO<sub>4</sub> were ground using the same method but in two separated jars. The method used followed the teachings of Examples 10, 11, and 12 from the Kamauchi patent. The grinding jar was charged with 2.37kg (750 pieces) of grinding media. The material to be ground was added to the jar. In the case of LiCoPO<sub>4</sub>, the soft cake of material from the heating was crushed by hand and added to the milling jar. In the case of LiFePO<sub>4</sub>, the hard cake of material from the heating was crushed with mortar and pestle until the particle size was less than about 1mm, then added to the milling jar. The jar mill was turned on and adjusted to 150+/-7 rpm. After 24 hours of grinding, the powder was separated from the grinding media with a coarse (2mm) sieve. After grinding, the color of the Li-Co-PO<sub>4</sub> positive electrode material mix powder was dark gray. The color of the LiFePO<sub>4</sub> powder was grayish beige.

#### Phase Analysis via X-ray diffraction

X-ray diffraction measurements were performed on the synthesized and ground materials. The X-ray diffraction patterns are shown in Figures 2 and 3. The pattern of the Li-Co-PO<sub>4</sub> material mix did not match that of LiCoPO<sub>4</sub> from literature. This was expected since it was a mixture. The pattern of the LiFePO<sub>4</sub> material matched XRD patterns for LiFePO<sub>4</sub> in the literature (stick pattern shown by black lines in Figure 3), but some impurity phases could be seen.

Figure 2. X-ray Diffraction Pattern of Li-Co-PO<sub>4</sub> Mixed Phase Material





Figure 3. X-ray Diffraction Pattern of  $\text{LiFePO}_4$  Material



#### Particle size analysis

Attempts were made to measure the particle size distribution with the Malvern Zetasizer ZEN3600 particle size analyzer. Approximately 0.1 g of the Li-Co- $\text{PO}_4$  mixed phase sample after 24 hour grinding was added to 20 mL of water. The mix was shaken by hand for 1 minute and sonicated in an ultrasonic bath for 30 minutes. However, during the duration (about 2 minutes) of analysis, a significant portion of the sample precipitated. The Malvern Zetasizer ZEN3600 particle size analyzer is designed for particles small enough not to precipitate out during measurement even without stirring. The fact that Li-Co- $\text{PO}_4$  mixed phase powder precipitated indicated that the particles were too large for the instrument. Because of this difficulty, samples of both the Li-Co- $\text{PO}_4$  mixed phase powder and  $\text{LiFePO}_4$  powder were sent to Micromeritics Analytical Services<sup>1</sup> for particle size analysis by a light scattering technique performed with a Micromeritics Saturn DigiSizer 5200 Particle size analyzer (which has a larger maximum size range than the ZEN3600). General descriptions of the analysis techniques available at Micromeritics are given in Appendix C. Standard method 520-01 (non-aqueous liquid dispersion) was chosen as the method. Isopropanol was chosen as the liquid for two reasons: (1) Isopropanol wets the samples very well. (2) All components, including possible impurities, in the samples are expected to be insoluble in isopropanol.

In the preparation of the dispersion, 2.2g of the sample was added to 80 mL of isopropanol. The dispersion was sonicated using a high intensity (100 W) ultrasonic probe for one minute in order to break any agglomerates of particles. An ultrasonic probe (instead of an ultrasonic bath) was used because of its much higher intensity. The analysis was done twice for each sample. The results reported here are the average of the two analyses. The particle size distribution can be shown as a volume distribution, or as a number distribution. The difference and relationship between the two is explained in Appendix D. The NanoGram patent application describes particle size distributions with

<sup>1</sup> Micromeritics Analytical Services, [www.particletesting.com](http://www.particletesting.com), One Micromeritics Drive, Norcross, Georgia 30093-1877. (770)772-3630

respect to a number distribution. However, it is also common to describe a particle size distribution with respect to volume distribution. Therefore, the data in this experiment is provided both ways. For the two samples, the particle size volume distributions are shown graphically in Figures 4 and 5. The particle size number distributions are shown graphically in Figures 6 and 7. The numerical values of cumulative volume fraction are shown in Tables 3 and 4.

Figure 4. Particle Size **Volume** Distribution of Li-Co-PO<sub>4</sub> Mixed-Phase Material




Figure 5. Particle Size **Volume** Distribution of LiFePO<sub>4</sub> Material






Figure 6. Particle Size Number Distribution of Li-Co-PO<sub>4</sub> Mixed-Phase Material




Figure 7. Particle Size Number Distribution of LiFePO<sub>4</sub> Material




Table 3. Cumulative **Volume** Fractions of Li-Co-PO<sub>4</sub> Mixed-Phase Material  
Smaller than a Particular Particle Size from Two Separate Measurement Runs.

Particle size (diameter in $\mu\text{m}$ )	% volume smaller than particle size				Particle size (diameter in $\mu\text{m}$ )	% volume smaller than particle size			
	Test 1	Test 2	Average	Standard Deviation		Test 1	Test 2	Average	Standard Deviation
0.073	0.00%	0.00%	0.00%	0.00%	3.668	45.95%	46.08%	46.02%	0.09%
0.082	0.01%	0.01%	0.01%	0.00%	4.116	48.38%	48.48%	48.43%	0.07%
0.092	0.02%	0.04%	0.03%	0.01%	4.618	50.72%	50.82%	50.77%	0.07%
0.103	0.05%	0.08%	0.07%	0.02%	5.182	52.98%	53.08%	53.03%	0.07%
0.116	0.10%	0.15%	0.12%	0.04%	5.814	55.17%	55.27%	55.22%	0.07%
0.130	0.17%	0.25%	0.21%	0.05%	6.523	57.32%	57.42%	57.37%	0.07%
0.146	0.28%	0.38%	0.33%	0.07%	7.319	59.49%	59.58%	59.53%	0.06%
0.164	0.43%	0.56%	0.50%	0.09%	8.213	61.72%	61.77%	61.75%	0.04%
0.184	0.65%	0.80%	0.73%	0.11%	9.215	64.01%	64.02%	64.02%	0.01%
0.206	0.95%	1.12%	1.04%	0.12%	10.339	66.31%	66.31%	66.31%	0.00%
0.231	1.35%	1.54%	1.44%	0.13%	11.600	68.59%	68.59%	68.59%	0.00%
0.260	1.86%	2.06%	1.96%	0.14%	13.016	70.82%	70.84%	70.83%	0.02%
0.291	2.51%	2.70%	2.61%	0.14%	14.604	73.03%	73.06%	73.04%	0.02%
0.327	3.30%	3.48%	3.39%	0.13%	16.386	75.25%	75.27%	75.26%	0.01%
0.367	4.23%	4.40%	4.32%	0.12%	18.386	77.50%	77.50%	77.50%	0.00%
0.412	5.31%	5.46%	5.38%	0.11%	20.629	79.76%	79.74%	79.75%	0.01%
0.462	6.52%	6.65%	6.59%	0.10%	23.146	82.00%	81.98%	81.99%	0.02%
0.518	7.85%	7.98%	7.91%	0.09%	25.970	84.18%	84.16%	84.17%	0.01%
0.581	9.28%	9.41%	9.35%	0.09%	29.139	86.27%	86.26%	86.27%	0.01%
0.652	10.81%	10.95%	10.88%	0.10%	32.695	88.27%	88.26%	88.27%	0.01%
0.732	12.43%	12.60%	12.52%	0.12%	36.684	90.19%	90.17%	90.18%	0.01%
0.821	14.16%	14.35%	14.26%	0.13%	41.160	91.98%	91.95%	91.96%	0.02%
0.921	16.01%	16.22%	16.12%	0.15%	46.182	93.58%	93.55%	93.56%	0.03%
1.034	18.01%	18.23%	18.12%	0.15%	51.817	94.96%	94.94%	94.95%	0.02%
1.160	20.17%	20.38%	20.27%	0.15%	58.140	96.12%	96.13%	96.12%	0.01%
1.302	22.48%	22.70%	22.59%	0.15%	65.234	97.08%	97.15%	97.11%	0.05%
1.460	24.95%	25.18%	25.06%	0.17%	73.194	97.89%	98.03%	97.96%	0.10%
1.639	27.53%	27.80%	27.66%	0.19%	82.125	98.57%	98.76%	98.67%	0.13%
1.839	30.19%	30.51%	30.35%	0.22%	92.146	99.13%	99.33%	99.23%	0.14%
2.063	32.89%	33.25%	33.07%	0.25%	103.389	99.54%	99.71%	99.63%	0.12%
2.315	35.59%	35.95%	35.77%	0.25%	116.005	99.82%	99.92%	99.87%	0.07%
2.597	38.26%	38.57%	38.41%	0.22%	130.159	99.95%	99.99%	99.97%	0.03%
2.914	40.88%	41.12%	41.00%	0.17%	146.041	100.00%	100.00%	100.00%	0.00%
3.269	43.45%	43.62%	43.53%	0.12%					

From the table, for example, only 0.07% of the volume of the powder is in particles smaller than 0.103 $\mu\text{m}$ , 1.04% smaller than 0.206 $\mu\text{m}$ , 7.91% smaller than 0.518 $\mu\text{m}$ , 18.12% smaller than 1.034 $\mu\text{m}$ , and 33.07% smaller than 2.063 $\mu\text{m}$ . The reproducibility of the two tests were excellent, as indicated by the small standard deviation.

Table 4. Cumulative **Volume** Fractions of LiFePO<sub>4</sub> Material Smaller than a Particular Particle Size from Two Separate Measurement Runs.

Particle size (diameter in $\mu\text{m}$ )	% volume smaller than particle size				Particle size (diameter in $\mu\text{m}$ )	% volume smaller than particle size			
	Test 1	Test 2	Average	Standard deviation		Test 1	Test 2	Average	Standard deviation
0.073	0.00%	0.00%	0.00%	0.00%	2.914	54.18%	54.23%	54.21%	0.04%
0.082	0.03%	0.03%	0.03%	0.00%	3.269	56.48%	56.51%	56.50%	0.02%
0.092	0.09%	0.10%	0.09%	0.01%	3.668	58.67%	58.69%	58.68%	0.02%
0.103	0.19%	0.22%	0.20%	0.02%	4.116	60.74%	60.77%	60.76%	0.02%
0.116	0.35%	0.38%	0.37%	0.03%	4.618	62.74%	62.77%	62.75%	0.02%
0.130	0.57%	0.62%	0.60%	0.04%	5.182	64.69%	64.72%	64.71%	0.02%
0.146	0.88%	0.95%	0.91%	0.05%	5.814	66.64%	66.67%	66.66%	0.03%
0.164	1.29%	1.37%	1.33%	0.06%	6.523	68.59%	68.64%	68.62%	0.04%
0.184	1.83%	1.93%	1.88%	0.07%	7.319	70.54%	70.62%	70.58%	0.06%
0.206	2.52%	2.64%	2.58%	0.08%	8.213	72.47%	72.57%	72.52%	0.07%
0.231	3.40%	3.53%	3.47%	0.09%	9.215	74.36%	74.46%	74.41%	0.07%
0.260	4.49%	4.62%	4.56%	0.09%	10.339	76.21%	76.28%	76.24%	0.05%
0.291	5.80%	5.94%	5.87%	0.09%	11.600	78.02%	78.05%	78.04%	0.02%
0.327	7.35%	7.48%	7.42%	0.09%	13.016	79.81%	79.81%	79.81%	0.00%
0.367	9.14%	9.25%	9.19%	0.08%	14.604	81.60%	81.58%	81.59%	0.01%
0.412	11.13%	11.23%	11.18%	0.07%	16.386	83.38%	83.37%	83.37%	0.01%
0.462	13.30%	13.39%	13.34%	0.06%	18.386	85.12%	85.14%	85.13%	0.01%
0.518	15.61%	15.69%	15.65%	0.06%	20.629	86.80%	86.84%	86.82%	0.03%
0.581	18.02%	18.10%	18.06%	0.05%	23.146	88.37%	88.42%	88.40%	0.03%
0.652	20.50%	20.58%	20.54%	0.06%	25.970	89.83%	89.85%	89.84%	0.02%
0.732	23.02%	23.11%	23.07%	0.06%	29.139	91.19%	91.19%	91.19%	0.00%
0.821	25.59%	25.69%	25.64%	0.07%	32.695	92.50%	92.48%	92.49%	0.02%
0.921	28.22%	28.33%	28.28%	0.08%	36.684	93.77%	93.73%	93.75%	0.03%
1.034	30.92%	31.03%	30.97%	0.08%	41.160	94.95%	94.93%	94.94%	0.02%
1.160	33.67%	33.78%	33.72%	0.08%	46.182	96.04%	96.04%	96.04%	0.00%
1.302	36.45%	36.55%	36.50%	0.07%	51.817	97.01%	97.05%	97.03%	0.03%
1.460	39.20%	39.29%	39.24%	0.06%	58.140	97.87%	97.95%	97.91%	0.05%
1.639	41.87%	41.95%	41.91%	0.06%	65.234	98.64%	98.73%	98.68%	0.06%
1.839	44.43%	44.51%	44.47%	0.06%	73.194	99.26%	99.34%	99.30%	0.06%
2.063	46.91%	47.00%	46.95%	0.06%	82.125	99.70%	99.75%	99.72%	0.04%
2.315	49.36%	49.44%	49.40%	0.06%	92.146	99.93%	99.94%	99.93%	0.01%
2.597	51.80%	51.87%	51.83%	0.05%	103.389	100.00%	100.00%	100.00%	0.00%
					109.515	100.00%	100.00%	100.00%	0.00%

From the table, for example, only 0.20% of the volume of the powder is in particles smaller than 0.103 $\mu\text{m}$ , 2.58% smaller than 0.206 $\mu\text{m}$ , 15.65% smaller than 0.518 $\mu\text{m}$ , 30.97% smaller than 1.034 $\mu\text{m}$ , and 46.95% smaller than 2.063 $\mu\text{m}$ . The reproducibility of the two tests were excellent, as indicated by the small standard deviation.

Table 5. Cumulative Number Fractions of Li-Co-PO<sub>4</sub> Mixed-Phase Material  
Smaller than a Particular Particle Size from Two Separate Measurement Runs.

Particle size (diameter in $\mu\text{m}$ )	% number smaller than particle size	Particle size (diameter in $\mu\text{m}$ )	% number smaller than particle size
0.075	1.33%	0.671	97.27%
0.080	3.60%	0.711	97.63%
0.085	6.52%	0.753	97.95%
0.090	9.88%	0.798	98.22%
0.095	13.54%	0.845	98.46%
0.100	17.39%	0.895	98.67%
0.106	21.36%	0.948	98.85%
0.113	25.39%	1.005	99.01%
0.119	29.44%	1.064	99.15%
0.126	33.49%	1.127	99.27%
0.134	37.51%	1.194	99.38%
0.142	41.48%	1.265	99.47%
0.150	45.37%	1.340	99.55%
0.159	49.18%	1.419	99.62%
0.169	52.89%	1.503	99.68%
0.179	56.49%	1.592	99.73%
0.189	59.96%	1.686	99.77%
0.200	63.29%	1.786	99.81%
0.212	66.47%	1.892	99.84%
0.225	69.50%	2.004	99.87%
0.238	72.36%	2.123	99.89%
0.252	75.05%	2.249	99.91%
0.267	77.57%	2.382	99.92%
0.283	79.91%	2.523	99.94%
0.300	82.08%	2.673	99.95%
0.318	84.07%	2.831	99.96%
0.336	85.89%	2.999	99.96%
0.356	87.55%	3.177	99.97%
0.378	89.05%	3.365	99.97%
0.400	90.39%	3.564	99.98%
0.424	91.59%	3.776	99.98%
0.449	92.66%	3.999	99.99%
0.475	93.61%	4.236	99.99%
0.503	94.44%	4.487	99.99%
0.533	95.17%	4.753	99.99%
0.565	95.81%	5.035	99.99%
0.598	96.36%	5.333	99.99%
0.634	96.85%	5.649	99.99%
		5.984	100.00%

From the table, for example, only 17.39% of the number of particles are smaller than 0.100 $\mu\text{m}$ , and 63.29% smaller than 0.200 $\mu\text{m}$ .

Table 6. Cumulative Number Fractions of LiFePO<sub>4</sub> Material Smaller than a Particular Particle Size from Two Separate Measurement Runs.

Particle size (diameter in $\mu\text{m}$ )	% number smaller than particle size	Particle size (diameter in $\mu\text{m}$ )	% number smaller than particle size
0.075	1.57%	0.598	97.77%
0.080	4.24%	0.634	98.11%
0.085	7.65%	0.671	98.40%
0.090	11.57%	0.711	98.65%
0.095	15.79%	0.753	98.86%
0.100	20.20%	0.798	99.03%
0.106	24.70%	0.845	99.18%
0.113	29.22%	0.895	99.31%
0.119	33.70%	0.948	99.42%
0.126	38.12%	1.005	99.52%
0.134	42.45%	1.064	99.59%
0.142	46.66%	1.127	99.66%
0.150	50.74%	1.194	99.72%
0.159	54.67%	1.265	99.77%
0.169	58.44%	1.340	99.81%
0.179	62.05%	1.419	99.84%
0.189	65.47%	1.503	99.87%
0.200	68.72%	1.592	99.89%
0.212	71.78%	1.686	99.91%
0.225	74.65%	1.786	99.92%
0.238	77.32%	1.892	99.94%
0.252	79.80%	2.004	99.95%
0.267	82.10%	2.123	99.96%
0.283	84.20%	2.249	99.96%
0.300	86.11%	2.382	99.97%
0.318	87.85%	2.523	99.97%
0.336	89.42%	2.673	99.98%
0.356	90.82%	2.831	99.98%
0.378	92.06%	2.999	99.99%
0.400	93.17%	3.177	99.99%
0.424	94.14%	3.365	99.99%
0.449	94.98%	3.564	99.99%
0.475	95.72%	3.776	99.99%
0.503	96.36%	3.999	99.99%
0.533	96.90%	4.236	100.00%
0.565	97.37%		

From the table, for example, only 20.20% of the number of particles are smaller than 0.100 $\mu\text{m}$ , and 68.72% smaller than 0.200 $\mu\text{m}$ .

## CONCLUSIONS

In this experiment, Li-Co-PO<sub>4</sub> mixed-phase material were synthesized using methods taught in United States Patent #5,538,714 (the "Kamauchi Patent"), and LiFePO<sub>4</sub> material was synthesized using the approaches of the Goodenough research group. Both materials were ground using the method in the Kamauchi Patent. After grinding, both powders were analyzed for particle size distribution. The results clearly indicated that the particles have a broad particle size distribution.

## APPENDIX

### A: US patent 5,538,814 - Lithium Secondary Batteries, Kamauchi et al.

For reference, the relevant parts of US Patent # 5,538,814 (the Kamauchi patent) are highlighted below

#### Example 1

Predetermined amounts of lithium carbonate, basic cobalt carbonate, and 85% phosphoric acid aqueous solution were weighed to fulfill an atomic ratio of Li:Co:P=2:1:1, sufficiently mixed in an alumina crucible, and heated at 900° C in an electric oven for twenty-four hours.

The heated product was identified by X-ray powder diffraction analysis with the use of JCPDS cards. The results of the X-ray analysis showed that the product contained lithium phosphate, lithium-cobalt phosphate, and cobalt oxide at a molar ratio of Li:Co:P=1:0.5:0.5

#### Example 10

The positive electrode active material obtained in Example 1 was further pulverized in a ball mill for 24 hours to adjust the average particle size thereof to about 0.5  $\mu$ m, and the BET specific surface area to 5 m<sup>2</sup>/g.

Twenty lithium batteries were fabricated in the same manner as in Example 1 by using this positive electrode.

#### Examples 11, 12

In the same manner as in Example 10 except that the average particle size, and the BET specific surface area of the positive electrode active material were changed as shown in Table 3 by varying the pulverizing time in a ball mill, 20 lithium batteries were fabricated in each Example.

The lithium batteries of Example 10-12 were charged in the same manner as above, and discharge capacity was determined, the results of which are shown in Table 7 wherein the figures are average values.

Partial Table 7

	Active material average particle size ( $\mu\text{m}$ )	BET specific surface area ( $\text{m}^2/\text{g}$ )
Example 10	0.5	5
Example 11	5	1
Example 12	0.01	800

### B. Padhi (1997) article on Phospho-olivines

The original publication on the use of  $\text{LiFePO}_4$  for lithium secondary batteries is "Phospho-olivines as Positive-Electrode Materials for Rechargeable Lithium Batteries", by A. K. Padhi, K. S. Nanjundaswamy, and J. B. Goodenough, Journal of The Electrochemical Society, Vol. 144, issue 4, page 1188-1193 (1997). A copy of this article is attached. For completeness, the most relevant parts of the article are highlighted below.

#### Experimental

$\text{LiMPO}_4$  ( $\text{M} = \text{Mn, Fe, Co, or Ni}$ ) compounds were prepared by direct solid-state reaction of stoichiometric amounts of  $\text{M(II)-acetates}$ , ammonium phosphate, and lithium carbonate.  $\text{LiFePO}_4$  and  $\text{LiFe}_{1-x}\text{Mn}_x\text{PO}_4$  ( $x = 0.25, 0.50, \text{ and } 0.75$ ) were synthesized in inert atmosphere to prevent the formation of  $\text{Fe}^{3+}$  compounds as impurities. The intimately ground stoichiometric mixture of the starting materials was first decomposed at  $300$  to  $350^\circ\text{C}$  to drive away the gases. The mixture was then reground and returned to the furnace at  $800^\circ\text{C}$  for  $24$  h before being cooled slowly to room temperature.

### C. Particle Size Analysis by Laser Light Scattering conducted a Micromeritics

Laser light scattering technique utilizes Mie and Fraunhofer Theories to determine particle size distribution from a light scattering pattern. Micromeritics has both the Saturn Digisizer 5200 and the Mastersizer 2000 available for this technique. The Mastersizer 2000 is capable of performing particle size distribution using either the dry dispersion module or wet dispersion module. The Saturn Digisizer 5200 is the highest resolution instrument available, capable of distinguishing small differences in samples. The particle size range is  $0.02 \mu\text{m}$  to  $2000 \mu\text{m}$ .

Available standard tests:

520 - 00

Particle size analysis using an aqueous dispersion. A distribution of particle size diameter is reported between  $0.1$  to  $1000$  micrometers. The technique requires at least  $2$  grams of dry sample material.


520 - 01

Particle size analysis using a non-aqueous dispersion. A distribution of particle size diameter is reported between  $0.1$  to  $1000$  micrometers. The technique requires at least  $2$  grams of dry sample material.

#### D. Relationship between volume distribution and number distribution

The result of particle size analysis is expressed as a distribution, which states what percentage of the powder sample is in each size range. If the percentage is based on volume of particles, the distribution is a volume distribution. Alternatively, if the percentage is based on number of particles, the distribution is a number distribution. The relationship between the two distributions is illustrated a very simple example. Assuming there are 4 particles with diameter 1  $\mu\text{m}$ , 3 particles with diameter 2  $\mu\text{m}$ , 2 particles with diameter 3  $\mu\text{m}$ , and 1 particle with diameter 4  $\mu\text{m}$ . The volume distribution and the number distribution are calculated in the table below, and shown in the figure below.

Particle Diameter	Number of particles	% of number of particles with that diameter	Vol of each particle	Sum of Vol of particles with that diameter	% of Vol of particles with that diameter
1	4	40%	0.524	2.09	3%
2	3	30%	4.189	12.57	16%
3	2	20%	14.137	28.27	37%
4	1	10%	33.510	33.51	44%
Sum of all particles	10			76.45	



From the example above, it can be understood that number distribution tends to show higher % for smaller particles, and volume distribution tends to show higher % for larger particles. Based on an assumption of uniform particle shape, each distribution can be converted from one representation to the other. As presented above, the particles were assumed to be spherical.